



1	CMT10-01	BASE PLATE
2	CMT10-02	SCREW
3	CMT10-03	FLAT WASHER
4	CMT10-04	FENDER
5	CMT10-05	WASHER
6	CMT10-06	FIXING KNOB
7	CMT10-07	BASE KNOB
8	CMT10-08	FLAT WASHER
9	CMT10-09	ADJUSTMENT BLOCK
10	CMT10-10	BASE KNOB
11	CMT10-11	BASE POSITION BLOCK
12	CMT10-12	SCREW
13	CMT10-13	DEPTH ADJUSTMENT BLOCK
14	CMT10-14	NUT
15	CMT10-15	OSITION LOCK MAST
16	CMT10-16	DUST GUARD
17	CMT10-17	CLAMP NUT
18	CMT10-18	COLLET 6mm
18	CMT10-18A	COLLET 6.35mm (OPTIONAL)
18	CMT10-18B	COLLECT 8mm
19	CMT10-19	MOTOR HOUSING
20	CMT10-20	SCREW
21	CMT10-21	RING
22	CMT10-22	BEARING 6002-2RZ
23	CMT10-23	CABLE AND PLUG
24	CMT10-24	CABLE ARMOR
25	CMT10-25	CABLE CLAMP
26	CMT10-26	SCREW
27	CMT10-27	DEPTH INDICATOR
28	CMT10-28	ELECTRIC RING
29	CMT10-29	BRUSH HOLDER
30	CMT10-30	CARBON BRUSH
31	CMT10-31	BRUSH COVER
32	CMT10-32	FIXING POLE
33	CMT10-33	PLASTIC GEAR
34	CMT10-34	STATOR
35	CMT10-35	PIN
36	CMT10-36	BEARING 627-2Z
37	CMT10-37	ANTI-DUST RING
38	CMT10-38	ARMATURE
39	CMT10-39	SCREW
40	CMT10-40	HOUSING
41	CMT10-41	LABEL
42	CMT10-42	SWITCH
43	CMT10-43	SWITCH POLE
44	CMT10-44	INDUCTANCE
45	CMT10-45	CAPACITOR
46	CMT10-46	LABEL
47	CMT10-47	REAR COVER
48	CMT10-48	GUIDE
52	CMT10-52	SPANER 12MM
53	CMT10-53	SPANER 17MM
54	CMT10-54	GUIDE BUSH



03\_60.0327